

mus



Imus

USA Manual

Instructions for use

Imus

Product specifications

Freestanding infrared heater.

Height:	26,5 inch
Width:	7,9 inch
Power source AC:	110V AC ~ 60 HZ
Power consumption:	0,55 kW
Protection class:	IP 44
Use Imus at temperatures below:	68 °F

- 1: On/Off switch
- 2: Heat protective grid
- 3: Foot
- 4: Ventilation holes
- 5: Handle




READ AND SAVE THESE INSTRUCTIONS

IMPORTANT INSTRUCTIONS / WARNING

- When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following: Arrange cord away from traffic area" after need to follow, and where it will not be tripped over."
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, blankets, and curtains at least 3 feet (0.9 m) from around the heater.
- Connect to properly grounded outlets only.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Always unplug heater when not in use
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked. (2),(4),(5)
- Do not use under a table with a tablecloth that extends more than 5 cm over the table edge.
- Do not place bags or other objects in such a way that they block the grid. (2)
- Do not insert or allow foreign objects to enter any ventilation or exhaus opening as this may cause an electric shock or fire, or damage the heater. (2),(4)
- Connect the product only to outlets with ground.
- Extreme caution is necessary when heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not operate heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair
- Do not run cord under carpeting. Do not cover cord with throw rugs, runner, or similar covering. Do not route cord under furniture or appliances. Arrange cord away from traffic areas.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Always plug heater directly into a wall outlet/receptacle. Never use with an extension cord or re locatable power tab (outlet/power strip)
- This heater includes a visual alarm to warn that parts of the heater are getting excessively hot. If the alarm flashes, immediately turn the heater off and inspect for any objects on or adjacent to the heater that may cause high temperatures.
 DO NOT OPERATE THE HEATER WITH ALARM FLASHING.
- Always take the product inside after use, and let the product cool off before packing it away (if applicable).
- Use this heater only as described in this manual. Any other use not recommended by manufacturer may cause fire, electric shock, or injury to persons.


Grounding instructions

This heater is for use on 110 volts. The cord has a plug as shown at A in Figure 1. An adapter as shown at C is available for connecting three-blade grounding-type plugs to two-slot receptacles. The green grounding lug extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box. The adapter should not be used if a three-slot grounded receptacle is available.



The on/off switch light will be on when connected to power and off when disconneted. Figure 1

Heating mode



USA

Imus is designed to heat two persons sitting on either side of a table. The optimum heat is achieved by placing Imus at the middle below the table. It will take about 1 minute from the time you switch on Imus until you feel the heat. To get the most out of Imus, you should position yourself in such a way that you get heat on the inside of both of your legs so that your body gets optimal utilisation of the heat. Press the On/Off switch (1) to turn off the product if you do not require further heat.

Maintenance and cleaning

- Disconnect the plug from the socket before cleaning or when the product is not in use for prolonged periods of time.
- Do not clean the product until 60 minutes after it is turned off.
- When cleaning, do not spray cleaners or water directly into the product.
- Apply the cleaner on a cloth and wipe the product.
- For cleaning of reflector plate, please remove the grills. Clean the reflector plate with a rag with glass cleaner, please DO NOT TOUCH the lamp with fingers or the cloth.
- For cleaning of the grills, please remove the grills. Clean the grills with a cloth with glass cleaner.
- Regular maintenance of the product is recommended, as this will prolong the product's service life and appearance (in coastal areas, the product should cleaned more frequently, due to atmospheric salinity).
- Regularly check the cord for damages and ensure that the plug is clean.
- If the power cord, lamp or other electrical parts needs replacing, this must be done only by a qualified professional.

Troubleshooting

Follow the troubleshooting steps listed below:

- Make sure the power cord is connected correctly.
- Check the cable for any ruptures.
- Make sure the On/ Off switch has been pressed.
- Check whether the bulb has blown.
- If the product is turned off due to overheating caused by improper use (overheat sensor), the product must be disconnected from the socket outlet and cool off. Check the product for defects after 30 minutes of cooling. If there are no visible defects, try to reconnect the product again.

Please contact the place of purchase if this did not solve your problem.

Disposal

The product should not be disposed of along with household waste. Instead, the product must be disposed of along electronic waste by dropping it off at collection points for recycling of electronic waste. To learn more about where you can drop off your electronic waste for recycling, contact your local authority or your local waste management authority.

Warranty

The product warranty is pursuant to the Danish Sale of Goods Act. The warranty period starts on the day the product was purchased. Small defects and minor cosmetic flaws that do not affect use of the product or decrease the value of the product are not covered by the warranty. The warranty must be proved by presenting an original receipt showing the purchase date and product name.

Warranty management

A defective product must be returned to the place of purchase along with a valid receipt. If the product becomes defective during the warranty period, the product must be returned to the place of purchase. Here, warranty-related repairs will be carried outon the product, if the defect pertains to the product or the production faults. Defects in the product will be tried rectified by repair or replacement of parts. In case of exchange of the product, the may occur differences in hue or model design compared to the purchased product.

Warranty disclaimer

Damage or defects resulting from neglect or improper use of the product is not covered by the warranty. Damage or defects resulting from the use of unoriginal replacement parts or unoriginal enhancements is not covered by warranty. The warranty does not cover force majeure such as lightning, flood, fire or damage occurred during transport. The warranty will be void if the product's serial number has been changed or if there modifications in any way are made to the product, or if the product is sought repaired by an outside third party.

Download manual

You can always download your manual online at: www.mensaheating.com/FAQ

<u>USA</u>



mus

USA: Contents of the Manual are subject to change.